


Pull 01

L13²⁵/₃₂ x P2¹¹⁶/₁₆" | L350 x P65mm

Install Instructions

Australian Design No. 202216355

Bankston
Edition Office



Finishes &
Materials



FAQs &
Warranty



Resources

bankston.com

@bankston_architectural



Bankston Australia
14-16 Stepney Street
Stepney, South Australia 5069

P. +61 (0)8 8362 1133
E. info@bankstonarchitectural.com.au

Bankston New Zealand
P. +64 (0)6 359 0008
E. info@bankstonarchitectural.co.nz

Bankston International
E. info@bankston.com

**SDG Trading Pty Ltd trading
as Bankston Architectural**

ACN 008 154 041
ABN 18 008 154 041

*Image used for illustration
purposes only



Please recycle
me after use

1. Marking the Door

- 1.1 Mark the top fixing point on the face of your door at the desired height and horizontal distance from door edge. (Figure 1)
- 1.2 In most instances, the vertical position should align with the centre of the door stile on a panel door or with any lock, turn or escutcheon fitted to the door. (Figure 1)
- 1.3 Using a spirit level, mark the bottom fixing point — noting the CTC measurement is 100mm starting 50mm up from base of pull handle. (Figure 2)

2. Fitting the Pull Handle (Concealed Fix Method)

- 2.1 Remove the pencil spindles from the pull handle by loosening the grub screws. (Figure 3)
- 2.2 Drill appropriate pilot holes for the wood screws at each of the pencil spindle locations. (Figure 4)
- 2.3 Fit pencil spindles using wood screws provided. (Figure 4)
- 2.4 Place pull handle on pencil spindles and tighten grub screws to secure. (Figure 5)




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5

3. Fitting the Pull Handle (Rear Fix Method)

- 3.1. Drill holes through door at the fixing points marked in step 1.3. (Figure 2)
- 3.2. It is important to drill halfway through the door from one door face and complete the hole from the other side to prevent splintering.
- 3.3. Insert fixing bolts through the holes from the inside of the door.
- 3.4. With pencil spindles already attached to the pull handle, align the female thread of the pencil spindle to the top fixing bolt and tighten. Repeat for bottom fixing point.

4. Fitting the Pull Handle (Affixing a Pair)

- 4.1. Drill holes through door at the fixing points marked in Figure 2.
- 4.2. It is important to drill halfway through the door from one door face and complete the hole from the other side to prevent splintering.
- 4.3. Remove pencil spindles on both pull handles by loosening grub screws.
- 4.4. Screw a pencil spindle onto one side of each threaded bolt.
- 4.5. Insert bolt through hole and screw pencil spindle onto opposite end of thread. Hand tighten and ensure pencil spindles are flush against the door faces. (Figure 6)
- 4.6. If required cut threaded bolt to allow pencil spindles to sit flush with door.
- 4.7. To prevent loosening, fix pencil spindles on each side with 2 x woodscrews. Repeat 4.2 – 4.6 at bottom fixing point.
- 4.8. Place pull handles on pencil spindles and tighten all grub screws to secure.

IMPORTANT

Please install this hardware in the following order to ensure its warranty is not voided.

Install the hardware on raw/unfinished door using the instructions provided.

Remove hardware (where possible) and store safely. Do not place tape onto the hardware as this will damage the finish.

Paint / finish door.

Reinstall hardware.




Figure 6






Figure 7

Included



Not Included



PLEASE NOTE

The screws provided with Bankston products are made from solid brass. This allows finishes to be matched as closely as possible and prevents the possibility of screws rusting in coastal areas.

Please note that screws require pre-drilling.

Please take extra care when fitting.

Dimensions

